


8 Beginning at front top remove door liner from channel while simultaneously pulling door liner away from interior door panel at bottom.


9 Unhook linkage to interior door actuating mechanism at front.

10 Disconnect electrical connections on door liner and guide wires through liner.



11 Lay door liner to side.

12 Check vapor seal on interior door panel, replace vapor seal if damaged.




13 Complete electrical connections on door liner, guide wires through liner.

14 Hook in linkage for interior door actuating mechanism at front.


15 Insert lock button into door liner at rear and press door liner into channel in interior sealing bar at top.

16 Engage plug-in clips on interior door panel in door liner (9 pieces).


17 Screw in the screws in area of door handle (2 each) and tighten.



18 Install cover plate on door lock and screw down. Screw in screw on door liner (arrows).




19 Install wooden cover; turn both catches to installed position.



20 Insert wooden cover with catches into recess in door covering.

Recess for catches on wooden cover



21 Press wooden cover forcefully at front to catch.

22 Reconnect and install entry light (1).

