

	Removing, installing	
1.1	Remove storage compartment (1) <i>CENTRAL ARM REST</i>	i Up to 31.08.01: Unclip stowage compartment (1) from stowage box (3)
2.1	Unscrew screws (2) and remove stowage box (3)	i up to 31.08.01
3	Unscrew screws (4).	
4	Remove armrest lid (5)	i As of 01.09.01: Insert long wedge into access openings (6) and loosen retaining lugs. 8 Long wedge *115589035900
5	Install in the reverse order	



	Remove/install		AR68.20-P-2370GH
1	Remove armrest cover from center console		
2	Disconnect connector (2) from left (S21/15s1) and right (S21/15s2) rear power window switch		
3	Remove left (S21/15s1) and right (S21/15s2) rear power window switch from cover (1)	! Danger of breaking clips i Unclip switches (4 clips) and remove toward inside	
4	Remove cover (1)	i Unclip cover and remove toward outside	
5	Install in the reverse order		