





- Parts list -

Mode	MD mode	Mod. des. overview	PASSENGER CAR,SEDAN, -N- MODEL YEAR '92 FEDERAL UP TO IDENT NO. WDBG34E.N A 087222
FIN/MD	140134	Catalog	19F
VIN		Major assembly	
Sales designation	300 SD TURBODIESEL USA; S 350 TURBODIESEL USA	Major assembly MD	
Assortment class	Car	Group	33 - FRONT AXLE
Market	North America	Subgroup	030 - STEERING KNUCKLE AND CONTROL ARM

Item no.	Part number	Designation/description	Quantity	Version
5	A 140 332 09 01	STEERING KNUCKLE Replaced by: A 140 332 08 01	-	
5	A 140 332 08 01	STEERING KNUCKLE LEFT	001	
5	A 140 332 09 02	STEERING KNUCKLE Replaced by: A 140 332 08 02	-	
5	A 140 332 08 02	STEERING KNUCKLE RIGHT	001	
11	A 140 333 03 27	JOINT	002	
14	N 913004 018003	NUT JOINT TO STEERING KNUCKLE	002	
17	A 124 330 01 80	PIN STEERING STOP	002	
20	A 140 332 04 20	STEERING ARM LEFT	001	
20	A 140 332 05 20	STEERING ARM RIGHT	001	
23	A 126 990 08 01	SCREW STEERING ARM TO STEERING KNUCKLE	004	
29	A 140 330 05 25	FRONT WHEEL HUB Replaced by: A 140 334 04 01  [011] FIRST EXHAUST STOCK OF OLD PARTS UP TO IDENT NO. A 159402	-	
29	A 140 334 04 01	WHEEL HUB Replaced by: A 140 330 03 25	-	
29	A 140 330 03 25	FRONT WHEEL HUB	002	
50	A 140 330 00 51	REPAIR KIT Replaced by: A 140 330 02 51  [016] FIRST EXHAUST STOCK OF OLD PARTS UP TO IDENT NO. B 232041	-	
50	A 140 330 02 51	REPAIR KIT FRONT WHEEL BEARING	002	
53	A 017 997 39 47	SEAL RING	002	
56	A 201 547 00 85	CONTACT SPRING FRONT WHEEL HUB TO STEERING KNUCKLE TO 140 330 00 51	002	
59	A 201 334 01 25	HUB CAP Replaced by: A 168 357 00 89	-	
59	A 168 357 00 89	LOCKING CAP FRONT WHEEL HUB TO STEERING KNUCKLE	002	
62	N 000912 006176	SCREW FRONT WHEEL HUB TO STEERING KNUCKLE	002	
65	A 116 334 03 72	NUT FRONT WHEEL HUB TO STEERING KNUCKLE	002	
71	A 140 330 42 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 64 07  [010] FIRST EXHAUST STOCK OF OLD PARTS UP TO IDENT NO. A 096694	-	
71	A 140 330 64 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 70 07	-	
71	A 140 330 70 07	TRANSVERSE CONTROL ARM BOTTOM LEFT	001	
71	A 140 330 43 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 65 07  [010] FIRST EXHAUST STOCK OF OLD PARTS UP TO IDENT NO. A 096694	-	
71	A 140 330 65 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 71 07	-	

71	A 140 330 71 07	TRANSVERSE CONTROL ARM BOTTOM RIGHT	001
86	A 140 330 54 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 58 07	-
86	A 140 330 58 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 76 07	-
86	A 140 330 76 07	TRANSVERSE CONTROL ARM TOP LEFT	001
86	A 140 330 55 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 59 07	-
86	A 140 330 59 07	TRANSVERSE CONTROL ARM Replaced by: A 140 330 77 07	-
86	A 140 330 77 07	TRANSVERSE CONTROL ARM TOP RIGHT	001
----	A 140 990 04 01	. SCREW UPPER TRANSVERSE CONTROL ARM [402] NO LONGER AVAILABLE	002
----	A 140 330 03 71	. CLAMPING PLATE [417] NO LONGER AVAILABLE; ORDER RANGE OF DELIVERY	002
104	A 140 333 07 40	BRACKET LOWER CONTROL ARM TO STEERING KNUCKLE, LEFT [851] UP TO END OF MODEL YEAR'95	001
104	A 140 333 08 40	BRACKET LOWER CONTROL ARM TO STEERING KNUCKLE, RIGHT [851] UP TO END OF MODEL YEAR'95	001
107	N 000960 012162	SCREW Replaced by: N 308676 012042	-
107	N 308676 012042	SCREW UPPER TRANSVERSE CONTROL ARM TO STEERING KNUCKLE	002
110	N 913004 012009	NUT UPPER TRANSVERSE CONTROL ARM TO STEERING KNUCKLE	002
113	N 913004 014002	NUT LOWER CONTROL ARM TO FRONT SUBFRAME	002
116	A 140 990 01 51	NUT ECCENTRIC PIN	004
119	A 124 990 16 12	SCREW UPPER CONTROL ARM TO FRAME	008
122	A 140 330 60 07	REPAIR KIT Replaced by: A 140 330 63 07 [010] FIRST EXHAUST STOCK OF OLD PARTS UP TO IDENT NO. A 096694	-
122	A 140 330 63 07	REPAIR KIT Replaced by: A 140 330 82 07 [014] Up to ident. no.: A 244052	-
122	A 140 330 82 07	TRANSVERSE CONTROL ARM LOWER CONTROL ARM TO FRONT SUBFRAME [015] As of ident. no. A 244053	002
----	A 140 330 00 85	REPAIR KIT LOWER CONTROL ARM JOINT BOOT [402] NO LONGER AVAILABLE	002
128	A 140 330 00 18	REPAIR KIT ECCENTRIC PIN	002