

Transmission gauge reading observations

Moving	Selector	modulating Pres.	Working Pres.	Notes:
No	Neutral	1.4	6.6	
				Going from 0 to 5 mph pressure would go up to 110, then drop to 70 and then 50 psi. At approx 5 to 10 mph pressure would go to 70 and then drop to 48 psi. Readings recorded with car moving at 40 mph per documentation.
Yes	Drive	2.1	3.2	
Yes	Reverse		6.6	Needle would dropped to 30 and then back to 90 psi