



Electric wiring diagram air-conditioning system 3rd version with Delco refrigerant compressor starting 08/80, model 123.1 standard version and (USA) starting model year 1981

- | | |
|---|---|
| <ul style="list-style-type: none"> 1 Blower switch with light 2 Pre-resistors 3 Blower 4 Main fuse box supplementary fuse C (16 amps. with supplementary heater 25 amps.) 5 Main fuse box fuse no. 8 (16 amps.) 6 Main fuse box fuse no. 12 (8 amps.) 7 Pressure switch receiver dehydrator (clutch refrigerant compressor) 8 Temperature dial with light | <ul style="list-style-type: none"> 9 Relay I air-conditioning system (code no. 12) 10 Electromagnetic clutch 13 Relay supplementary fan (code no. 6) 14 Temperature switch (52 °C) 16 Supplementary fan 17 Temperature sensor air-conditioning system 18 Switchover valve for fresh air-recirculating air flap a Rotary light switch terminal 8 b Instrument cluster terminal 58 d |
|---|---|