

# CRUISE CONTROL (WITH AUTOMATIC TRANSMISSION)


AS OF MY 1986

DIESEL

137/1

124.1

Supplement 10



FOR CRUISE CONTROL TO BE ENGAGED, TERMINAL 8 MUST SENSE GROUND. WHEN STOP LAMP SWITCH IS CLOSED, GROUND IS ELECTRICALLY REMOVED.