



Function diagram 1, function selection "a" (defrosting)

- 13 Switchover valve for center nozzle flap
14 Switchover valve for leg room flaps
15 Switchover valve for defroster nozzle flaps
16 Switchover valve for vacuum elements of fresh air-recirculated air flap and main air flap (small stroke)
17 Switchover valve for vacuum elements of fresh air-recirculated air flap and main air flap (large stroke)
18 Switchover valve for scoop air flap
35 Vacuum connection on intake pipe
36 Check valve
37 Vacuum reservoir
38 Vacuum element for defroster nozzle flaps (flaps "open")
39 Vacuum element for leg room flaps (flaps "closed")
40 Vacuum element for center nozzle flap (flap "closed")
41 Vacuum element for scoop air flap (flap "closed")
42 Vacuum element for fresh air-recirculated air flap and main air flap (flap "open", 100 % fresh air supply)
43 Vacuum element for fresh air-recirculated air flap and main air flap (flap "open", 100 % fresh air supply)
44 Orifice
45 Check valve
48 7-point distributor
49 4-point distributor
50 3-point distributor