



P07-0496-57

| | | | |
|----|---|-----|--|
| 1 | Injection pump | 73a | Restriction orifice in fuel filter top section dia. 0.8 mm |
| 3 | Fuel pump | 86 | Fuel thermostat open, position up to + 8 °C, fuel is preheated |
| 15 | Bypass valve with restriction dia. 1.5 mm | 86a | Fuel thermostat closed, position as from + 25 ° C, fuel is no longer preheated. |
| 30 | Injection nozzles | 87 | Inlet line - cold fuel |
| 43 | Fuel prefilter | 87a | Return line - preheated fuel |
| 50 | Leak oil hose | 148 | Heater inlet pipe with fuel heat exchanger |
| 54 | Injection line, No. 1 cylinder | | |
| 63 | Fuel tank | | |
| 73 | Fuel filter top section | | |