


Functional diagram, air injection and exhaust gas recirculation



- | | | | |
|-----|-----------------------------|-----|-------------------------------------|
| 89 | EGR valve | 156 | Exhaust manifold |
| 123 | Throttle valve housing | N3 | CIS-E control unit |
| 125 | Air injection pump | N16 | Engine systems control unit (MAS) |
| 126 | Air injection shutoff valve | Y27 | EGR switchover valve 1 |
| 127 | Check valve (air injection) | Y32 | Air injection pump switchover valve |
| 128 | Check valve (vacuum) | Y33 | Electromagnetic air pump clutch |