


B. Engine 119.97/98



P05-5018-57

- | | | | |
|------------|------------------------------------|------------|---|
| 1 | Crankshaft timing gear | 14 | Slide rail, inside left of cylinder head |
| 2 | Bearing pin | a = 8.1 mm | |
| 3 | Tensioning rail | b = 9 mm | |
| 4 | Chain tensioner | 15 | Inlet camshaft timing gear |
| 5 | Exhaust camshaft timing gear | 16 | Top slide rail |
| 6 | Top slide rail | 17 | Exhaust camshaft timing gear |
| 7 | Inlet camshaft timing gear | 25 | Timing chain, 216 double links |
| 8 | Slide rail, right of cylinder head | 26 | Slide rail, outside left of cylinder head |
| a = 8.1 mm | | a = 8.1 mm | |
| b = 9 mm | | b = 9 mm | |
| 9 | Slide rail pin | 27 | Slide rail pin |
| 10 | Slide rail pin | 28 | Slide rail pin |
| 11 | Guide pulley | 29 | Slide rail, crankcase |
| 12 | Slide rail pin | a = 8.1 mm | |
| 13 | Slide rail pin | b = 9 mm | |
| | | 30 | Bearing pin bolted |
| | | 31 | Bearing pin bolted |