

FUSE/RELAY BOX

AS OF MY 1986

RELAY CODE	RELAY USE
No Code	Heated Rear Window Relay
No Code	Overvoltage Protection Relay
10	Power Window Relay
32	Air Injection Management Relay

NOTE: Relays are shown in their typical position. They can be arranged in different positions. Use codes to determine proper relay.

REVISIONS: