	 453 - windshield (laminated glass) and two-tone horn (from 01.01.1964 up to 31.05.1972)
_	454 - tank lock (from 01.01.1964 up to 31.10.1974)
454	 454 - International taxi and tachometer (from 01.08.1980 up to 31.10.1993)
	• 454 - 451 + 452 (from 01.01.1963 up to 30.09,1963)
\neg	455 - tank lock and windshield (laminated glass)
455	 455 - International taxi and tank lock (from 01.09.1972 up to 31.10.1974)
	 455 - International taxi, tachometer and two-tone horn (from 01.08.1980 up to 31.10.1993) 455 - 451 + 454 (from 01.01.1964 up to 31.05.1973)
	• 455 - 451 + 454 (from 01.01.1964 up to 31.05.1972)
456	 456 - tank lock and two-tone horn (from 01.01.1964 up to 31.10.1974)
	 457 - tank lock and windshield (laminated glass) as well as two-tone horn (from 01.01.1964 up to 31.05.1972)
457	 457 - International taxi, two-tone horn and tank lock (from 01.09.1972 up to 31.10.1974)
458	 458 - tachometer and two-tone horn (from 01.12.1972 up to 28.02.1993)
459	
460	460 - instrument km/h and bumpers for Canada (from 01.05.1977 up to 30.09.1995) 460 - vehicles for Canada additional parts (from 01.10.1005)
700	460 - vehicles for Canada, additional parts (from 01.10.1995)
461	 461 - instrument with mileage reading and english lettering (from 01.04.1990)
	 462 - tuning of fuel injection pump for USA fuel (from 01.11.1962 up to 31.03.1966)
	462 - rear fog lamp
462	462 - rear fog lamp (from 01.07.1968 up to 31.12.1976)
	• 462 - 460 + 461 (from 01.08.1966 up to 30.04.1968)
	463 - instrument km/h for Canada (from 01.05.1977)
463	463 - vehicles for Canada, additional parts and central locking system
	 463 - hazard warning light with headlamp system (from 01.05.1967 up to 31.08.1969) 463 - spark plug with heat value 235 for USA (from 01.10.1966 up to 31.12.1966)
	463 - 461 + 462 (from 01.11.1962 up to 31.03.1966)
	464 - spark plug with heat value 235 for USA tourists (from 01.10.1966 up to 31.12.1966)
464	464 - 461 + 463 (from 01.02.1968 up to 31.08.1969)
165	465 - rear fog lamp and instruments with english letter (from 01.07.1968 up to 31.12.1976)
465	• 465 - 461 + 463 (from 01.10.1966 up to 31.12.1966)
	466 - central locking system (from 01.04.1970 up to 31.10.1993)
466	• 466 - 461 + 464 (from 01.10.1966 up to 31.12.1966) • 466 - 463 + 463 (from 01.07.1968 up to 31.08.1969)
	• 466 - 462 + 463 (from 01.07.1968 up to 31.08.1969)
467	 467 - central locking system and instruments with english lettering (from 01.04.1970 up to 31.10.1 467 - 461 + 462 + 463 (from 01.07.1068 pp to 21.06.1060)
	• 467 - 461 + 462 + 463 (from 01.07.1968 up to 31.08.1969)
169	468 - central locking system and rear fog lamp 468 - 462 + 466 (from 01.04.1070) - 468 - 462 + 466 (from 01.04.1070)
468	• 468 - 462 + 466 (from 01.04.1970 up to 31.12.1976)
469	469 - central locking system and instruments with englishlettering
	 469 - 461 + 462 + 466 (from 01.04.1970 up to 31.12.1976)