


HOT IN RUN OR START



1.5 BK/YL/GN

C148

1.5 RD

1 BK



IN-LINE
RADIO
FUSE



RADIO



1 BR

1 BR

C148

1.6 BR

G102

- 1 Automatic antenna
- 2 Antenna switch
- 3 Radio
- E Retracting position
- A Extending position
- ... Tipping position (in antenna switch 2)
- Detent position (in antenna switch 2)
- g Fuse automatic antenna (terminal 30)
- h Fuse, radio (terminal 15 R)

