



Mercedes-Benz

AP00.20-U-1208DE

SERVICE SHEET for Mercedes-Benz Maintenance System (USA)

Model Year 2009

USA

Model 211



Customer: _____

Repair order number: _____

Tire Rotation
(non-staggered width
wheel setup only)

A 5,000-mile recommended tire rotation
interval will likely necessitate tire rotation
at least once in between each 10,000-mile
maintenance service and at every 10,000-
mile maintenance service.

Tires rotated YES ☐ NO ☐

i Note: For any condition found while performing the checks or inspections included in this maintenance sheet, determine the cause and perform the repair using a separate repair order.

Current mileage reading: _____

Oil grade/viscosity: _____

Additional notes: _____

Service work to be performed as advised by
service advisor:

Completion date:

Confirm work has been performed by signing
below:

| Required Service Work | miles (thousands) | 2 | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | |
|---|-------------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|------------|------------|------------|------------|------------|-----|---|
| years | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | | Not OK ↓ |
| <input checked="" type="checkbox"/> Performed (check if performed) | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Reset maintenance service indicator in instrument cluster | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | AP00.20-P-0042TA |
| <input type="checkbox"/> Rear axle differential fluid replacement (only E 63 AMG with AMG performance package) | • | | | | • | | | | • | | | | • | | | | | |
| <input type="checkbox"/> Engine - oil and filter change | | | | | | | | | | | | | | | | | | |
| Engine 272, 273 | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | AP18.00-P-0101TS |
| Engine 156 | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | AP18.00-P-0101TMG |
| Engine 642 | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | AP18.00-P-0101TI |
| <input type="checkbox"/> Check catch, safety catch and hinges on engine hood for proper operation | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP88.40-P-8851T |
| <input type="checkbox"/> Check condition of poly-V-belt | | | | | | | | | | | | | | | | | | |
| Engine 272, 273, 156 | | | • | | • | | • | | • | | • | | • | | • | | • | <input type="checkbox"/> AP13.22-P-1352TS |
| Engine 642 | | | • | | • | | • | | • | | • | | • | | • | | • | <input type="checkbox"/> AP13.22-P-1352TI |
| <input type="checkbox"/> Replace fuel filter | | | | | | | | | | | | | | | | | | |
| Engine 272, 273, 156 | | | | | | | | | | | | | | | | | • | AP47.20-P-0780TC |
| Engine 642 | | | • | | • | | • | | • | | • | | • | | • | | • | AP47.20-P-0780TI |
| <input type="checkbox"/> Replace coolant | | | | | | | | | | | | | | | | | | |
| Engine 272, 273 | | | | | | | | | | | | | | | | | • | AP20.00-P-2080DA |
| Engine 156 | | | | | | | | | | | | | | | | | • | AP20.00-P-2080TMG |
| Engine 642 | | | | | | | | | | | | | | | | | • | AP20.00-P-2080BA |
| <input type="checkbox"/> Replace brake fluid | | | • | | • | | • | | • | | • | | • | | • | | • | AP42.00-P-4280T |
| Check the following fluid levels, correct if necessary | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check coolant level | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AH20.00-P-1142-01V |
| <input type="checkbox"/> Brake system | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP42.10-P-4210Z |
| <input type="checkbox"/> Power steering | | | | | | | | | | | | | | | | | | |
| <i>i</i> The fluid level must always be on the maximum mark, corresponding to the oil temperature. | | | | | | | | | | | | | | | | | | |
| Engine 272, 273, 156 | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP46.00-P-4611BB |
| Engine 642 | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP46.00-P-4611P |
| <input type="checkbox"/> Windshield washer system | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP82.35-P-8210N |
| Function check | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Parking brake (function test only) | | | • | | • | | • | | • | | • | | • | | • | | • | <input type="checkbox"/> |
| <input type="checkbox"/> Replace combination filter | | | • | | • | | • | | • | | • | | • | | • | | • | AP83.00-P-8384T |
| <input type="checkbox"/> Check thickness of brake pads, front and rear | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP42.10-P-4253A |
| <input type="checkbox"/> Correct tire inflation pressure and enter in bar or psi: | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> |
| LF RF LR RR | | | | | | | | | | | | | | | | | | |
| bar/psi: _____ | | | | | | | | | | | | | | | | | | |
| miles (thousands) | 2 | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | | |
| years | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | | |

| miles (thousands) years | 2 | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | |
|---|---|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|---|
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | | |
| <input type="checkbox"/> Check inflation pressure in spare tire (if applicable) and enter in bar or psi: bar/psi: _____ | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> |
| <input type="checkbox"/> Leakage - Major components Check underbody and engine compartment for chafe marks, line routing, damaged components. | | • | | • | | • | | • | | • | | • | | • | | | <input type="checkbox"/> AP00.20-P-0053BA |
| <input type="checkbox"/> Visually inspect condition of front axle ball joints, rubber boots | | • | | • | | • | | • | | • | | • | | • | | | <input type="checkbox"/> |
| <input type="checkbox"/> Visually inspect condition of driveshaft flexible discs | | • | | • | | • | | • | | • | | • | | • | | | <input type="checkbox"/> AP41.10-P-4152Z |
| <input type="checkbox"/> Visually inspect condition of steering mechanical components, rubber boots | | • | | • | | • | | • | | • | | • | | • | | | <input type="checkbox"/> |
| <input type="checkbox"/> Automatic transmission - oil and filter change | | | | • | | | | • | | | | • | | | | | AP27.00-P-2702W |
| <input type="checkbox"/> Transfer case - oil change (4MATIC models) | | | | • | | | | | | | | | | | | | AP28.00-P-2801P |
| <input type="checkbox"/> Replace air filter Engine 272, 273 Engine 156 Engine 642 | | | | | • | | | • | | | | • | | | | | AP09.10-P-0980TS AP09.10-P-0980TMG AP09.10-P-0980TI |
| <input type="checkbox"/> Replace spark plugs Engine 272, 273 Engine 156 | | | | | | | | • | | | | | | | | | AP15.10-P-1580TS AP15.10-P-1580TMG |
| <input type="checkbox"/> Reminder: Reset maintenance service indicator in instrument cluster | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | AP00.20-P-0042TA |
| Recommended Service Work <input checked="" type="checkbox"/> Performed (check if performed) | | | | | | | | | | | | | | | | | Not OK ↓ |
| Check the following fluid levels, correct if necessary | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Main or starter battery | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP54.10-P-5410A |
| Electrical system checks | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Horn, high beam flasher, hazard warning flasher, turn signals | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> |
| <input type="checkbox"/> Warning/indicator lamps, illumination and interior lighting/exterior lighting | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP54.30-P-5452C |
| <input type="checkbox"/> Check trunk/cargo area lighting | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> |
| <input type="checkbox"/> Check and correct headlamp setting | | • | | • | | • | | • | | • | | • | | • | | | <input type="checkbox"/> AP82.10-P-8260T |
| <input type="checkbox"/> Battery (main/starter/auxiliary) check condition using "Midtronics MCR 717" tester. Attach Midtronics MCR 717 Test Report print out here | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP54.10-U-5453A |
| Visual and functional checks | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check seat belts and buckles for signs of external damage and proper function | | • | | • | | • | | • | | • | | • | | • | | | <input type="checkbox"/> AP91.40-P-9150M |
| miles (thousands) years | 2 | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | | |

| miles (thousands) years | 2 | 10 1 | 20 2 | 30 3 | 40 4 | 50 5 | 60 6 | 70 7 | 80 8 | 90 9 | 100 10 | 110 11 | 120 12 | 130 13 | 140 14 | 150 15 | |
|--|---|---------|---------|---------|---------|---------|---------|---------|---------|---------|-----------|-----------|-----------|-----------|-----------|-----------|--|
| <input type="checkbox"/> Check windshield washer and headlamp cleaning system | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP82.30-P-8252A |
| <input type="checkbox"/> Check, clean, and lubricate tilt/sliding roof mechanism (where applicable) | | | • | | • | | • | | • | | • | | • | | • | | <input type="checkbox"/> AP77.20-P-7731A |
| <input type="checkbox"/> Check, clean, and lubricate panoramic roof mechanism (where applicable) | | | • | | • | | • | | • | | • | | • | | • | | <input type="checkbox"/> AP77.20-P-7732PB |
| <input type="checkbox"/> Check bodywork for paintwork damage | | | • | | • | | • | | • | | • | | • | | • | | <input type="checkbox"/> AP98.00-P-9850BA |
| Tire checks | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Tire rotation (where applicable) | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | |
| <input type="checkbox"/> Inspect tires for damage, measure thread depth and enter in mm: <div style="display: flex; justify-content: space-around;"> <div>LF</div> <div>RF</div> <div>LR</div> <div>RR</div> </div> outside _____ center _____ inside _____ | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP40.10-P-4051Z |
| <input type="checkbox"/> Check TIREFIT tire sealant expiration date (where applicable) | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP40.10-P-4054R |
| <input type="checkbox"/> Activate Tire Pressure Monitoring System; Refer to vehicle Operator's Manual | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | |
| Chassis checks | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Visually check brake system components, lines, hoses, calipers | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> |
| <input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed Pads Discs | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | <input type="checkbox"/> AP42.10-P-4253A <input type="checkbox"/> AP42.10-P-4258R |
| <input type="checkbox"/> Check chassis and load-bearing body components for damage and corrosion | | | • | | • | | • | | • | | • | | • | | • | | <input type="checkbox"/> AP00.20-P-0090SX |
| <input type="checkbox"/> Replace wiper blades | | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | |
| miles (thousands) years | 2 | 10 1 | 20 2 | 30 3 | 40 4 | 50 5 | 60 6 | 70 7 | 80 8 | 90 9 | 100 10 | 110 11 | 120 12 | 130 13 | 140 14 | 150 15 | |
| High Mileage Required Service Work at 160,000 miles or 16 years; then every 20,000 miles or 2 years <input type="checkbox"/> Plus any applicable additional work listed at the end of this service sheet <input checked="" type="checkbox"/> Performed (check if performed) Not OK ↓ | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Reset maintenance service indicator in instrument cluster | | | | | | | | | | | | | | | | | AP00.20-P-0042TA |
| <input type="checkbox"/> Engine - oil and filter change Engine 272, 273 Engine 156 Engine 642 | | | | | | | | | | | | | | | | | AP18.00-P-0101TS AP18.00-P-0101TMG AP18.00-P-0101TI |
| <input type="checkbox"/> Check catch, safety catch and hinges on engine hood for proper operation | | | | | | | | | | | | | | | | | <input type="checkbox"/> AP88.40-P-8851T |
| <input type="checkbox"/> Check condition of poly-V-belt Engine 272, 273, 156 Engine 642 | | | | | | | | | | | | | | | | | <input type="checkbox"/> AP13.22-P-1352TS <input type="checkbox"/> AP13.22-P-1352TI |
| <input type="checkbox"/> Replace fuel filter Engine 642 | | | | | | | | | | | | | | | | | AP47.20-P-0780TI |
| <input type="checkbox"/> Replace brake fluid | | | | | | | | | | | | | | | | | AP42.00-P-4280T |

| | |
|---|---|
| Check the following fluid levels, correct if necessary | |
| <input type="checkbox"/> Check coolant level | <input type="checkbox"/> AH20.00-P-1142-01V |
| <input type="checkbox"/> Brake system | <input type="checkbox"/> AP42.10-P-4210Z |
| <input type="checkbox"/> Power steering <i>i</i> The fluid level must always be on the maximum mark, corresponding to the oil temperature. Engine 272, 273, 156 Engine 642 | <input type="checkbox"/> AP46.00-P-4611BB AP46.00-P-4611P |
| <input type="checkbox"/> Windshield washer system | <input type="checkbox"/> AP82.35-P-8210N |
| Function check | |
| <input type="checkbox"/> Parking brake (function test only) | <input type="checkbox"/> |
| <input type="checkbox"/> Replace combination filter | AP83.00-P-8384T |
| <input type="checkbox"/> Check thickness of brake pads, front and rear | <input type="checkbox"/> AP42.10-P-4253A |
| <input type="checkbox"/> Correct tire inflation pressure and enter in bar or psi: LF RF LR RR bar/psi: | <input type="checkbox"/> |
| <input type="checkbox"/> Check inflation pressure in spare tire (if applicable) and enter in bar or psi: bar/psi: | <input type="checkbox"/> |
| <input type="checkbox"/> Leakage - Major components Check underbody and engine compartment for chafe marks, line routing, damaged components. | <input type="checkbox"/> AP00.20-P-0053BA |
| <input type="checkbox"/> Visually inspect condition of front axle ball joints, rubber boots | <input type="checkbox"/> |
| <input type="checkbox"/> Visually inspect condition of driveshaft flexible discs | <input type="checkbox"/> AP41.10-P-4152Z |
| <input type="checkbox"/> Visually inspect condition of steering mechanical components, rubber boots | <input type="checkbox"/> |
| <i>i</i> Reminder: Reset maintenance service indicator in instrument cluster | AP00.20-P-0042TA |
| High Mileage Recommended Service Work at 160,000 miles or 16 years; then every 20,000 miles or 2 years <input checked="" type="checkbox"/> Performed Not OK (check if performed) ↓ | |
| Check the following fluid levels, correct if necessary | |
| <input type="checkbox"/> Main or starter battery | <input type="checkbox"/> AP54.10-P-5410A |
| Electrical system checks | |
| <input type="checkbox"/> Horn, high beam flasher, hazard warning flasher, turn signals | <input type="checkbox"/> |
| <input type="checkbox"/> Warning/indicator lamps, illumination and interior lighting/exterior lighting | <input type="checkbox"/> AP54.30-P-5452C |
| <input type="checkbox"/> Check trunk/cargo area lighting | <input type="checkbox"/> |
| <input type="checkbox"/> Check and correct headlamp setting | <input type="checkbox"/> AP82.10-P-8260T |
| <input type="checkbox"/> Battery (main/starter/auxiliary) check condition using "Midtronics MCR 717" tester. Attach Midtronics MCR 717 Test Report print out here | <input type="checkbox"/> AP54.10-U-5453A |

| | | | | | | | | | | | | | | | | |
|--|---|--|--|--|--|--------|--|--|--|--|--------|--|--|--|--|--|
| Visual and functional checks | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check seat belts and buckles for signs of external damage and proper function | <input type="checkbox"/> AP91.40-P-9150M | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check windshield washer and headlamp cleaning system | <input type="checkbox"/> AP82.30-P-8252A | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check, clean, and lubricate tilt/sliding roof mechanism (where applicable) | <input type="checkbox"/> AP77.20-P-7731A | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check, clean, and lubricate panoramic roof mechanism (where applicable) | <input type="checkbox"/> AP77.20-P-7732PB | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check bodywork for paintwork damage | <input type="checkbox"/> AP98.00-P-9850BA | | | | | | | | | | | | | | | |
| Tire checks | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Tire rotation (where applicable) | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Inspect tires for damage, measure thread depth and enter in mm: <div style="display: flex; justify-content: space-around; margin-top: 5px;"> LF RF LR RR </div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">outside</td> <td style="width: 15%; border-bottom: 1px solid black;"></td> <td style="width: 15%; border-bottom: 1px solid black;"></td> <td style="width: 15%; border-bottom: 1px solid black;"></td> <td style="width: 15%; border-bottom: 1px solid black;"></td> </tr> <tr> <td>center</td> <td style="border-bottom: 1px solid black;"></td> <td style="border-bottom: 1px solid black;"></td> <td style="border-bottom: 1px solid black;"></td> <td style="border-bottom: 1px solid black;"></td> </tr> <tr> <td>inside</td> <td style="border-bottom: 1px solid black;"></td> <td style="border-bottom: 1px solid black;"></td> <td style="border-bottom: 1px solid black;"></td> <td style="border-bottom: 1px solid black;"></td> </tr> </table> | outside | | | | | center | | | | | inside | | | | | <input type="checkbox"/> AP40.10-P-4051Z |
| outside | | | | | | | | | | | | | | | | |
| center | | | | | | | | | | | | | | | | |
| inside | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check TIREFIT tire sealant expiration date (where applicable) | <input type="checkbox"/> AP40.10-P-4054R | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Activate Tire Pressure Monitoring System; Refer to vehicle Operator's Manual | | | | | | | | | | | | | | | | |
| Chassis checks | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Visually check brake system components, lines, hoses, calipers | <input type="checkbox"/> | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed <div style="margin-top: 10px;"> Pads <input type="checkbox"/> AP42.10-P-4253A Discs <input type="checkbox"/> AP42.10-P-4258R </div> | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check chassis and load-bearing body components for damage and corrosion | <input type="checkbox"/> AP00.20-P-0090SX | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Replace wiper blades | | | | | | | | | | | | | | | | |
| High Mileage Required Service Work at 170,000 miles or 17 years; then every 20,000 miles or 2 years <input type="checkbox"/> Plus any applicable additional work listed at the end of this service sheet | | | | | | | | | | | | | | | | |
| <input checked="" type="checkbox"/> Performed (check if performed) | Not OK ↓ | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Reset maintenance service indicator in instrument cluster | AP00.20-P-0042TA | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Engine - oil and filter change <div style="margin-top: 5px;"> Engine 272, 273 AP18.00-P-0101TS Engine 156 AP18.00-P-0101TMG Engine 642 AP18.00-P-0101TI </div> | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check catch, safety catch and hinges on engine hood for proper operation | <input type="checkbox"/> AP88.40-P-8851T | | | | | | | | | | | | | | | |
| Check the following fluid levels, correct if necessary | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Check coolant level | <input type="checkbox"/> AH20.00-P-1142-01V | | | | | | | | | | | | | | | |
| <input type="checkbox"/> Brake system | <input type="checkbox"/> AP42.10-P-4210Z | | | | | | | | | | | | | | | |

| | |
|---|--|
| <input type="checkbox"/> Power steering <input type="checkbox"/> i The fluid level must always be on the maximum mark, corresponding to the oil temperature. <div style="display: flex; justify-content: space-between;"> Engine 272, 273, 156 <input type="checkbox"/> AP46.00-P-4611BB </div> <div style="display: flex; justify-content: space-between;"> Engine 642 <input type="checkbox"/> AP46.00-P-4611P </div> | |
| <input type="checkbox"/> Windshield washer system | <input type="checkbox"/> AP82.35-P-8210N |
| <input type="checkbox"/> Check thickness of brake pads, front and rear | <input type="checkbox"/> AP42.10-P-4253A |
| <input type="checkbox"/> Correct tire inflation pressure and enter in bar or psi: <div style="display: flex; justify-content: space-around; margin-top: 5px;"> LF RF LR RR </div> bar/psi: _____ _____ _____ _____ | <input type="checkbox"/> |
| <input type="checkbox"/> Check inflation pressure in spare tire (if applicable) and enter in bar or psi: bar/psi: _____ | <input type="checkbox"/> |
| <input type="checkbox"/> i Reminder: Reset maintenance service indicator in instrument cluster | AP00.20-P-0042TA |
| High Mileage Recommended Service Work at 170,000 miles or 17 years; then every 20,000 miles or 2 years <input checked="" type="checkbox"/> Performed Not OK (check if performed) ↓ | |
| Check the following fluid levels, correct if necessary | |
| <input type="checkbox"/> Main or starter battery | <input type="checkbox"/> AP54.10-P-5410A |
| Electrical system checks | |
| <input type="checkbox"/> Horn, high beam flasher, hazard warning flasher, turn signals | <input type="checkbox"/> |
| <input type="checkbox"/> Warning/indicator lamps, illumination and interior lighting/exterior lighting | <input type="checkbox"/> AP54.30-P-5452C |
| <input type="checkbox"/> Check trunk/cargo area lighting | <input type="checkbox"/> |
| <input type="checkbox"/> Battery (main/starter/auxiliary) check condition using "Midtronics MCR 717" tester. Attach Midtronics MCR 717 Test Report print out here | <input type="checkbox"/> AP54.10-U-5453A |
| Visual and functional checks | |
| <input type="checkbox"/> Check windshield washer and headlamp cleaning system | <input type="checkbox"/> AP82.30-P-8252A |
| Tire checks | |
| <input type="checkbox"/> Tire rotation (where applicable) | |
| <input type="checkbox"/> Inspect tires for damage, measure thread depth and enter in mm: <div style="display: flex; justify-content: space-around; margin-top: 5px;"> LF RF LR RR </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> outside _____ _____ _____ _____ </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> center _____ _____ _____ _____ </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> inside _____ _____ _____ _____ </div> | <input type="checkbox"/> AP40.10-P-4051Z |
| <input type="checkbox"/> Check TIREFIT tire sealant expiration date (where applicable) | <input type="checkbox"/> AP40.10-P-4054R |
| <input type="checkbox"/> Activate Tire Pressure Monitoring System; Refer to vehicle Operator's Manual | |

| | | | |
|--|--|--------------------------|--------------------------|
| Chassis checks | | | |
| <input type="checkbox"/> Visually check brake system components, lines, hoses, calipers | | | <input type="checkbox"/> |
| <input type="checkbox"/> Check thickness of brake pads and discs, front and rear wheels removed | | | |
| Pads | | <input type="checkbox"/> | AP42.10-P-4253A |
| Discs | | <input type="checkbox"/> | AP42.10-P-4258R |
| <input type="checkbox"/> Replace wiper blades | | | |
| High Mileage Additional Work | | | |
| <input checked="" type="checkbox"/> Performed (check if performed) | | | |
| <input type="checkbox"/> Replace fuel filter | | | |
| Engine 272, 273, 156 | If more than 150,000 mi or 15 years since last replacement | | AP47.20-P-0780TC |
| <input type="checkbox"/> Replace coolant | | | |
| Engine 272, 273 | If more than 150,000 mi or 15 years since last replacement | | AP20.00-P-2080DA |
| Engine 156 | If more than 150,000 mi or 15 years since last replacement | | AP20.00-P-2080TMG |
| Engine 642 | If more than 150,000 mi or 15 years since last replacement | | AP20.00-P-2080BA |
| <input type="checkbox"/> Automatic transmission - oil and filter change | If more than 40,000 mi or 4 years since last replacement | | AP27.00-P-2702W |
| <input type="checkbox"/> Rear axle differential fluid replacement (only E 63 AMG with AMG performance package) | If more than 40,000 mi or 4 years since last replacement | | |
| <input type="checkbox"/> Replace air filter | | | |
| Engine 272, 273 | If more than 40,000 mi or 4 years since last replacement | | AP09.10-P-0980TS |
| Engine 156 | If more than 40,000 mi or 4 years since last replacement | | AP09.10-P-0980TMG |
| Engine 642 | If more than 40,000 mi or 4 years since last replacement | | AP09.10-P-0980TI |
| <input type="checkbox"/> Replace spark plugs | | | |
| Engine 272, 273 | If more than 80,000 mi or 8 years since last replacement | | AP15.10-P-1580TS |
| Engine 156 | If more than 80,000 mi or 8 years since last replacement | | AP15.10-P-1580TMG |